Instructions sheet

UNLOADING TANKERS



Object

This instruction is intended to define the specific safety instructions for unloading tanks (in correlation with SEC.INS.FAB.008).

It completes the loading/unloading protocol (SEC.ENR.DTI.013).

Responsibilities

ACO Carrier Receiving Authority (RA) Drivers hired by the transport company (TC).

Description

AGGREGATE AND RESIN OBLIGATION TO:	
☐ Read the safety instructions before any operation (SEC.ENR.FAB.005)	and sign the document to take these into account
	0.014)
Consult the risk analysis document (SEC.INS.FAE	5.014)
☐ Present the route and delivery documents	
☐ Follow the instructions on the silos	
☐ Place at the designated and intended location	
☐ Wear mandatory PPE required and provided by th	e TC (helmet + glasses + earplugs + gloves + safety
shoes + covering clothing)	
☐ Ensure proper condition of the depotting pipes	
$\ \square$ Connect hose to tank or silo as indicated by RA re	epresentative
☐ Use the user company's pump or compressor	
☐ Monitor the depotting operation for its entire dura	tion
☐ Respect the cleanliness of the site	
FOR AGGREGATES OBLIGATION OF: FOR RESIN OBLIGATION OF:	
☐ Put the protectives pads under the crutches	☐ Present the document of registration of the
☐ Maximum unloading pressure: 0.8 bar	nature of the goods (UN and ADR code)
☐ Degassing through the valve provided for this	☐ Connect the tank to the ground cable
purpose	☐ Maximum unloading pressure: 0.5 bar
	☐ Open the RA valve only after hose connection

(description of use of the RA's Depotting Cabinet):

Instructions sheet

UNLOADING TANKERS



When the tank is almost full, a first alert
level (flashing red button + ringing) warns that you
must stop unloading. A second level of alarm
automatically closes the valve.
 Upon first alert level, stop pump and
close truck valve, immediately notify EA person
responsible for unloading.
☐ Close the EA valve before disconnecting from
the hose.

AGGREGATE AND RESIN PROHIBITION OF:

Connect to a silo and start the depotting without authorization
Decompress through the discharge valve
Mount on the elevated tank
Hammer the tank
Exceed max pressure to remove
Clean the tank in the factory enclosure
Smoking on cita